



MODEL NO. - ACM- 82305



VACUUM PUMP

ROTARY



VACUUM PUMP- ROTARY

These rotary oil sealed pumps are quiet operating and vibration less designed for continuous duty and factory tested to assure a satisfactory performance. The pump mechanism is contained in metal case with oil level sight gauge and drains plug at base. Motor driven pumps are completely mounted on rectangular base plate and are furnished with V belt, Single stage. S-25 Displacement Ltr / Min 25, Motor H.P. 0.25.

FREE AIR DISPLACEMENT WITH PERFECT EQUIVALENT MOTOR

(a) 25 LPM (Single / Double Stage)	¼ HP
(a) 50 LPM (Single / Double Stage)	¼ HP
(c) 75 LPM (Double stage)	¼ HP
(d) 100 LPM (Double stage)	½ HP
(e) 150 LPM (Double stage)	½ HP
(f) 200 LPM (Double stage)	1 HP
(g) 300 LPM (Double stage)	2 HP
(h) 500 LPM (Double stage)	3 HP

OPTIONAL ACCESSORIES

- (a) Moisture Trap
- (b) Non Return Value
- (c) Air blast
- (d) Vacuum Gauge With regulator
- (e) Vacuum (high grade oil)



SALIENT FEATURES

- High Efficiency
- Elegant in appearance
- Robust in construction
- Compact in design and minimum in weight
- Fitted with inbuilt Air Ballast
- Quick and easy oil changing arrangement
- Easy inspection of oil through window
- Thoroughly tested on McLeod gauge
- Ready availability of spares
- Models up to 200 ltrs are air cooled type with single phase Motor
- Models beyond this capacity are provided with water cooling jackets with three phase motor

APPLICATIONS

- Evacuation of Vacuum Systems
- Bulbs
- Neon Signs
- A.C.and Refrigeration
- Vacuum flasks
- Transformers
- Vacuum Moulds
- Drying
- Filling
- Lifting
- Forming
- Bright Annealing
- Impregnation
- Filtration
- Distillation
- Leak-Testing



An ISO 9001 : 2208 | ISO 14001 : 2008 | ISO 13485
WHO: GMP Products | GLP Compliant Products

www.acmasindia.com | www.acmasglobal.com | www.test-chambers.com

ACMAS TECHNOLOGIES PVT. LTD.

CORPORATE OFFICE/ SHOWROOM (INDIA)

Plot No. 352-353, Sector – 57
Phase- IV Kundli, Sonapat, Haryana - 131028
Land Line No.: +91 - 11- 47619688,
Fax: +91-11-47619788
E-mail.: info@acmasindia.com

SALES OFFICE (HONG KONG)

Unit D 28 11/F Wing Tat Comm,Bidg 97, Bonham Strand East,
Sheung Wan, Hong Kong (PRC)
Tel.: 0086-13929598046 | 0086- 18922303099
E-mail.: hk@acmasindia.com

SALES OFFICE (RUSSIA)

Inmed Trade Street Ozerkovsky Embankment,
Unit No 50, Straine- 1, Off- 502, Moscow, Russia
E-mail.: info@acmasindia.com
Tel.: 0049- 79592345 | Email: russia@acmasindia.com